

400 Series **Woodwright®**
Double-Hung Insert Window

Sill Angle Finder

1. Cut out this template and place against side jamb, keeping edge vertical against stop.
2. Fold bottom of template until it matches your sill angle.
3. Choose either 0°, 8°, or 14° Woodwright sill as determined by the fold in the template.

Place this edge against stop - keep vertical

OUTSIDE ROOM SIDE

